



2 Ohm Doppelschwingspule
2 Ohm Dual Voice Coil
=
1 Ohm



GROUND ZERO GmbH

Erlenweg 25; D - 85658 Eggenheim Phone 08095/873 830 Fax -8310 www.ground-zero-audio.com


2 Ohm Doppelschwingspule
2 Ohm Dual Voice Coil
=
4 Ohm



GROUND ZERO GmbH

Erlenweg 25; D - 85658 Eggenstein Phone 08095/873 830 Fax -8310 www.ground-zero-audio.com


4 Ohm Doppelschwingspule
4 Ohm Dual Voice Coil
=
2 Ohm



GROUND ZERO GmbH

Erlenweg 25; D - 85658 Eggenstein Phone 08095/873 830 Fax -8310 www.ground-zero-audio.com


4 Ohm Doppelschwingspule
4 Ohm Dual Voice Coil
=
8 Ohm



GROUND ZERO GmbH

Erlenweg 25; D - 85658 Eggenstein Phone 08095/873 830 Fax -8310 www.ground-zero-audio.com


4 Ohm Einzelschwingspule
4 Ohm Single Voice Coil
=
1 Ohm



GROUND ZERO GmbH

Erlenweg 25; D - 85658 Eggenstein Phone 08095/873 830 Fax -8310 www.ground-zero-audio.com

4 Ohm Einzelschwingspule
4 Ohm Single Voice Coil
=
4 Ohm



GROUND ZERO GmbH

Erlenweg 25; D - 85658 Eggening Phone 08095/873 830 Fax -8310 www.ground-zero-audio.com